

IoT Geräte

- Grid Frequency (ENTSOe)
- Ecoflow


Grid Frequency (ENTSOe)

Anzeige der aktuellen Netzfrequenz im europäischen Verbundnetz. Aktualisierung ca. 5 Sekunden.


Zugriff: Direkt

EDGE: nicht benötigt

Datenpunkt



Konfiguration



Ecoflow

Zugriff auf die Leistungsdaten der Ecoflow Powerstations über den vom Anbieter bereitgestellten MQTT Broker.

Zugriff: Direkt

EDGE: nicht benötigt

Datenpunkt



Konfiguration

Corrently

[Shop](#) [Service & Hife](#) [Impressum](#)

Ecoflow to Current Import

Ecoflow Powerstations might be controlled via the Ecoflow APP. This page allows to add data from the API to your [Corrently Current](#) display.

Disclaimer

This page and its script is provided by [STROMDAO GmbH](#). The company is not affiliated with Ecoflow or in any other relationship. This [page/script](#) is provided "as-is" without warranty or support. It is for the educational use of developers and enthusiasts.

Login Credentials from Ecoflow APP

Email	<input type="text"/>
Password	<input type="password"/>
Serial Number of Device	<input type="text" value="(Something like R611ZEB5XF12345)"/>
<div><button>Cancel / Return</button><button>Retrieve and Import to Current</button></div>	